

Dishwasher Detergent Uni

DESCRIPTION

A universal machine dishwasher detergent tough on on daily stains and dirt providing excellent cleaning results, delivering a positive customer experience with spotless and safe dishware, glassware and silverware.

- · Suitable for medium hard water conditions
- NTA, EDTA, phosphate and chlorine-free
- Excellent cleaning results in one pass washing, reducing water and energy usage, saving time and money



USE INSTRUCTIONS

For use in professional dishwashing machines. Always attempt to wash full machines whenever possible. Only for use with Dosing Unit. If "empty product" warning device is not installed, check detergent level regularly and change bottles when necessary.

Replacing Empty Bottle

- 1. Always wear recommended PPE when handling the product
- Remove cap from empty bottle and carefully remove the suction pipe NOTE: Never mix chemicals, if you are changing products, rinse the suction pipe with water first otherwise blockages may occur
- 3. Remove empty container and place new container in the basket
- Remove cap and carefully reinsert the suction pipe back into the new bottle
- 5. Retighten the cap
- 6. Dispose of empty containers responsibly, always replace the cap

APPLICATION

For professional use only.

Suitable for mechanical warewashing of all washable tableware including glassware, crockery, cutlery, bowls and all food preparation utensils. Do not use on aluminium and other soft metals.

SAFETY & STORAGE

 For further information and safety instructions, please see product label and Safety Data Sheet

PRODUCT CODE

2x5L

152652



